

Weighing scale-reader

2.737 Mechatronics

Instructor: Prof. David L. Trumper

Key takeaway: Oversampling for noise reduction.

Code Overview

- Field Programmable Gate Array (FPGA)
 - Reads C/AI0 at 333 kHz as a 12-bit integer value, and
 - Oversampling Implemented: Takes a moving average with 320 previous values and converts the result into fixed point.
 - Effectively, the fidelity (tracking of AI without too much phase lag) of the output oversampled AI signal is about $0.5 * 333 / 320 = 520.83$ Hz. (multiplying by 0.5 due to Shannon-Nyquist criterion)
 - We are trading off throughput (limiting how fast dynamics we can perceive from the AI signal) for lower noise and hence better resolution.
 - For more information, refer to - <http://www.cypress.com/file/236481/download>
- Real-Time
 - Reads the oversampled C/AI0 from the FPGA.
 - Has operations for filtering, converging voltage to load and implements the “tare” function.

Oversampling


Oversampling implemented (320:1)

Acquired Data

Raw input



Filtered



Oversampling implemented (320:1)

Effective resolution increase:

$$w = \frac{\log(N_{avg})}{\log(4)}$$

$N_{avg} = 320$ sample average,
 $w = 4.17$

The system effectively should
behave as a 16-bit ADC.

16-bit resolution:
 $20/2^{16} = 0.305$ mV


Measurement:

10 times better
resolution and lower
noise than original.

Total spread:



Max-Min = 0.778 mV


Histogram of 5000 values - 320:1 oversampling



Original 12-bit Analog input


Waveform Chart

Ref.>  Plant Output> 



Original 12-bit Analog input

Histogram of 5000 values - No oversampling




12-bit resolution:
 $20/2^{12} = 4.883 \text{ mV}$


Total spread:
Max-Min = 9.776 mV

Code screenshots


Front Panel




Block diagram



Signal I/O While Loop




Low-pass filtering While Loop



Tasks

Modify the 3 sub-VIs

- Implement any further filtering if you would like.
- Write to code to convert from voltage to weight measurement.
- Write code to implement tare functionality on pressing the tare button.



Double-click to open [sub-VI](#) and modify to implement your own code.

References

- <https://forums.ni.com/t5/Example-Programs/Convert-Sine-Wave-Generator-Raw-Output-to-Fixed-Point/ta-p/3530621>
- <https://forums.ni.com/t5/LabVIEW/Moving-Average-Filter/td-p/2550513>
- <https://terpconnect.umd.edu/~toh/spectrum/Smoothing.html>
- <http://www.cypress.com/file/236481/download>